

AKTV8

APP INSTRUCTION GUIDE

INTRODUCTION

Welcome to PressureTech. We appreciate your interest in leveraging this technology to support your needs. The purpose of this guide is to provide a high-level understanding of getting started with PressureTech. If you have any questions installing or getting started with this app, please contact **1 (888) 342-3162**.



STEP 1:**Download and Install the PressureTech App**

- Open the App Store or Google Play Store on your device.
- Search for the PressureTech app recommended for your specific PressureTech device.
- Tap on the PressureTech app icon.
- Tap the "Install" or "Get" button to download and install the app.

STEP 2:**Turn on Bluetooth**

- Open the "Settings" app on your device.
- Look for the "Bluetooth" option and tap on it.
- Toggle the Bluetooth switch to turn it on. The switch should turn green or indicate that Bluetooth is now enabled.

STEP 3:**Open PressureTech**


- Locate the PressureTech app icon on your devices home screen.
- Tap on the app icon to launch PressureTech

STEP 4:**Configure PressureTech**


- Upon opening PressureTech, you'll be taken to the home screen interface at the bottom, tap "Add Vehicle".
- On the configuration page, fill in all required fields.
- Select axle type: single axle or dual axle.
- Select numbers of axles for your configuration.
- Select layout to either be for TPMS, LOAD or both.
- Tap "Submit" to add the configuration to the apps home screen.

STEP 5:**Adding and Configuring Bluetooth Devices**


- Select your vehicle from the home screen.
- To pair tires on the TPMS tab, tap the corresponding tire and tap "Add" on the pop-up window.
- Use your devices camera to scan the QR code located on top of the sensor, or type the six digit MAC ID.
- On the axle load tab, tap the settings wheel in the top right corner. Tap the eye icon and use your devices camera to scan the QR code located on the sensor. Tap "Save".

**STEP 6:****Configuring TPMS**

- Select your vehicle from the home screen. Tap on the TPMS tab.
- Tap on the settings wheel in the top right corner to configure settings.
- Set pressure warnings as appropriate (PSI) and tap save.

**STEP 7:****Configuring Axle Load**

- Select your vehicle from the home screen. Tap on the Axle Load tab.
- Tap on the settings wheel in the top right corner to calibrate the vehicles empty weight and heavyweight. Set the overweight warning limit and tap "Save".



STEP 8:**Email Notifications**

- On the apps home page, tap the drop down in the upper right hand corner.
- Select "Settings".
- Tap "Configure Emails".
- Add your email addresses and tap "Save".

STEP 9:**Monitor Tire Pressure and Load**

- Once the PressureTech app is configured it will start receiving real-time data from the TPMS and LOAD device via Bluetooth.
- The app will display the tire pressure readings, vehicle weight and any relevant alerts on your devices screen.
- Stay informed about your tire pressure and weight to ensure it remains within the recommended range.

